
6x6m Party Tent Assembly Guide




Part List






Warning!:

- In some countries approval is needed to set up a tent larger than 75 m2.
- 2. The owner of the tent has the sole responsibility to make sure that these local rules are followed and that the mounting is correct.
- 3. It is always recommended that you secure your tent properly with storm straps and ground pegs when you put up the structure.
- 4. In case of extreme weather conditions the tent cover must be removed.
- 5. This structure is not tested for specific snow and wind loads.
- 6. Do not use open fire, welding equipment or other ignition sources in the tent.
- 7. We recommend you to insure the tent, or check if it is covered by home contents insurance, in case of unplanned events, accidents or bad weather.




Step 1: Lay out and connect the basic shape as shown above.Step 2: Fasten the connections as shown in I.







Step 3: Build up the roof structure as shown above, **Step 4:** Put no. 01 through the collected No. A, B & C and Screw on the top (No. 17) with the screwdriver (No. 07).



Step 5: Put the roofcover on the frame.Step 6: Raise the structure one side at a time using the legs.




Step 7: Secure the legs to the roof structure as shown in III. **Step 8:** Place the feet (no. E) on the structure an connect them with theground bars (No. 05).




Step 09: Secure the structyre to the ground using Stake pegs (No. 19).

Step 10: Pull down the roofcover and Secure it to the split on the feet as shown in IV

Step 11: Tighten the roofcover using the Crank (No. 02) as shown above. **DANCOVER**_®



Step 12: Use the bungeeballs (No. 16) to place the sidewalls (No. 15 & 16) And tie them down using the stake pegs (No. 19).



Step 13: Tie the guy lines(No. 14) into the corners of the gazebo and fasten them to the ground using the large stake pegs (No. 18).

DANCOVER

Contact Information	
Contact Information	
Head office: Dancover A/S Nordre Strandvej 119 G 3150 Hellebæk Danmark	DANCER
National Contact:	
Denmark:	Spain:
mail@dancover.dk	Espana@dancover.com
70267620	902 906 098
UK:	Italy:
Mail@dancover.co.uk	italia@dancover.com
020 7221 0220	02 303 75317
Germany:	Switzerland:
mail@dancover.de	schweitz@dancover.com
041 0266 7040	0840000125
France:	Austria:
france@dancover.com	austria@dancover.com
0810 000 219	0662 626 935
Sweden:	Norway:
mail@dancover.se	mail@dancover.dk
040 233 262	231 00 690